



Only install one inductor per cell. Two are shown to allow two different physical sizes.  
That is, install L1 or L3, and install L2 or L4


SIZE	FSCM NO.	DWG NO.	REV
SCALE		Low pass	




	SIZE	FSCM NO.	DWG NO.	REV
	SCALE		175	




		REV	
		SIZE	FSCM NO.
		DWG NO.	500
		SCALE	



		REV	
		1400	
		SCALE	
		1400	
		DWG NO.	
		FSCM NO.	
		SIZE	
		1400	



SIZE	FSCM NO.	DWG NO.	REV
SCALE		4000	



SIZE	FSCM NO.	DWG NO.	REV
SCALE		High Pass	