



NOTES:
 If regulators are not needed/used, do not install the associated components such as C1, R15, R16, R17, and D1 for the LM317, and C4, R20, R21, R22, and D3 for the LM337.
 Solder a jumper between the IN and OUT pins respectively in place of the unused regulator, pins 2 and 3 in each case.
 The LEDs and respective current limiting resistor only need to be installed if the circuit load is insufficient for the respective regulator.
 See the LM317 and LM337 data sheet for minimum load specifications.
 * 2 resistors: Matched 47k to 0.1%.
 ** 4 resistors: Matched value from 10k to 47k to 0.1%. Metal Film

SP_VPM_1.2	
TITLE: Voltage Processor	
Document Number:	
REV:	REV:
Date: 3/1/2012 10:20:12 PM	Sheet: 1/1