



ENVDT_COM is an inter-PCB wire which connects to the ENVDT board and "COMMONS" the output of ENVDT with ENVDL 1 and/or ENVDL2.

See the ENVDT schematic for the connection point.

The EG does not use the U+/U- or -10 volt connections. You only need to connect the +12 volt connection and do not need the -10 volt regulator or extra filter components for the U+/U- connections

Copyright 1976, 2010 Nyle Steiner and Analogue Realities. All rights reserved

SPENVDL_1.4	
TITLE: Envelope Duration Level Type 1 & 2	
Document Number:	REV:
Date: not saved!	Sheet: 1/1