



**NOTES:**

If regulators are not needed/used, do not install the associated components

such as C1, R1, R3, R4, and D1 for the LM317, and

C5, R5, R7, R8, and D3 for the LM337.

Solder a jumper between the IN and OUT pins respectively in place of the unused regulator, pins 2 and 3 in each case.

The LEDs and respective current limiting resistor only need to be installed

if the circuit load is insufficient for the respective regulator.

See the LM317 and LM337 data sheet for minimum load specifications.

|                                       |            |
|---------------------------------------|------------|
| SP_PwrReg_1.1                         |            |
| TITLE: Power filtering and regulation |            |
| Document Number:                      | REV:       |
| Date: 1/2/2015 4:05 PM                | Sheet: 1/1 |

Copyright 2010 Nyle Steiner and Analogue Realities. All rights reserved