



NOTES:

- If regulators are not needed/used, do not install the associated components such as C1, R1, R3, R4, and D1 for the LM317, and C5, R5, R7, R8, and D3 for the LM337.
- Solder a jumper between the IN and OUT pins respectively in place of the unused regulator, pins 2 and 3 in each case.
- The LEDs and respective current limiting resistor only need to be installed if the circuit load is insufficient for the respective regulator.
- See the LM317 and LM337 data sheet for minimum load specifications.

SP_Keyboard_Power_Distribution_1.0	
TITLE: Power filtering and regulation	REV:
Document Number:	Sheet: 1/1
Date: 4/7/2012 1:53:05 AM	

Copyright 2012 Analogue Realities. All rights reserved